



TYPICAL LINER BOOT DETAIL

NOTES:

- 1) BASE AROUND PILE SHALL BE LEVEL & COMPACT.
- 2) LINER & LINER BOOT SHALL BE CLEAN & DRY. A PRIMER IS RECOMMENDED FOR CLEANING.
- 3) BRUSH A THIN UNIFORM COAT OF PLASTIC ADHESIVE ON THE LINER BOOT FLANGE AT LEAST 2" WIDE ALONG THE FLANGE PERIMETER OF THE BONDING SURFACE.
- 4) USE A ROLLER TO APPLY PRESSURE TO THE LINER MEMBRANE & LINER BOOT FLANGE. ENSURE THAT FOLDS ARE REMOVED ALONG THE SEAM.
- 5) THE CHEMICAL BOND TIME IS AFFECTED BY HEAT & PRESSURE, ALLOW AT LEAST 24 HRS. FOR CURING.
- 6) PLACE THE BANDING CLAMP AROUND THE LINER BOOT & PIPE. TIGHTEN THE BANDING CLAMP AROUND THE PIPE & LINER BOOT.
- 7) APPLY A BEAD OF CAULKING BETWEEN THE LINER BOOT & PIPE ABOVE THE BANDED CLAMP & A BEAD ALONG THE CHEMICAL BONDED LINER SEAM.

		MILEPOST MFG. a div. of MILEPOST OILFIELD SERVICES LTD.		JOB#	
Designed by S.D.	Checked by —	Approved by - date —	Filename	Date 06/04/06	Scale NTS
			LINER BOOT DETAIL		
			CHEMICAL WELD		Edition 0
					Sheet 1/1